



PUCK

Hook

Krog

Haken

Krok

Crochet

Gancio

Gancho

Hakiem

Design: VE2



Zone Denmark



@zonedenmark



Zone Denmark

ZONE[®]
D E N M A R K

www.zonedenmark.dk



OPHÆNG

Det er meget vigtigt at overfladerne er rene og glatte – både m.h.t. væg og selve sugekoppen på Puck'en.

Derudover skal der en lille smule fugt til, så det vil være en rigtig god ide at tørre sugekoppen af med en fugtig klud inden ophæng.

Inden ophæng skruer man Puck'en så langt ud man kan, uden at den falder fra hinanden, og derefter presser man let på Pucken, mens man samtidig skruer helt i bund. Det er ikke nødvendigt at skrue voldsomt hårdt til sidst, da man så kan komme til at "over-skrue". Men der skal skrues helt i bund, så man fornemmer, at der er et rigtigt godt og fast greb mellem sugekop og væg (eller anden overflade).

HOW TO MOUNT

It is extremely important for the surfaces to be clean and smooth - on both the wall and the actual suction disc on the Puck.

There also needs to be a little bit of moisture, so it is a really good idea to wipe the suction disc with a damp cloth before mounting.

Before mounting, unscrew the Puck as far as you can without it falling apart, and then lightly press on the Puck, while at the same time turning it all the way down. You do not need to turn terribly hard at the end; otherwise you might "over-tighten". But you do need to turn it all the way, so you feel that there is a really good, solid grip between the suction disc and the wall [or other surface].